



## Attaching the Blades to the Wind Generator

1. Remove the blades from the box



2. Attach each blade to the hub with two screws (from the hub)



3. Make sure the distance between the blade tips is exactly the same, to avoid vibrations




4. Attach the hub to the rotor shaft with the M16 nut



5. Make sure the hub doesn't wobble when spinning (this will also avoid vibration)



6. Attach the nose cone by pressing it against the hub



7. Start enjoying free energy from the wind!